

§ 34.46

(3) Methods for controlling access to radiographic areas;

(4) Methods and occasions for locking and securing radiographic exposure devices, transport and storage containers and sealed sources;

(5) Personnel monitoring and the use of personnel monitoring equipment;

(6) Transporting sealed sources to field locations, including packing of radiographic exposure devices and storage containers in the vehicles, placarding of vehicles when needed, and control of the sealed sources during transportation (refer to 49 CFR parts 171-173);

(7) The inspection, maintenance, and operability checks of radiographic exposure devices, survey instruments, transport containers, and storage containers;

(8) Steps that must be taken immediately by radiography personnel in the event a pocket dosimeter is found to be off-scale or an alarm ratemeter alarms unexpectedly.

(9) The procedure(s) for identifying and reporting defects and noncompliance, as required by 10 CFR part 21 of this chapter;

(10) The procedure for notifying proper persons in the event of an accident;

(11) Minimizing exposure of persons in the event of an accident;

(12) Source recovery procedure if licensee will perform source recovery;

(13) Maintenance of records.

(b) The licensee shall maintain copies of current operating and emergency procedures in accordance with §§ 34.81 and 34.89.

§ 34.46 Supervision of radiographers' assistants.

Whenever a radiographer's assistant uses radiographic exposure devices, associated equipment or sealed sources or conducts radiation surveys required by § 34.49(b) to determine that the sealed source has returned to the shielded position after an exposure, the assistant shall be under the personal supervision of a radiographer. The personal supervision must include:

(a) The radiographer's physical presence at the site where the sealed sources are being used;

(b) The availability of the radiographer to give immediate assistance if required; and

(c) The radiographer's direct observation of the assistant's performance of the operations referred to in this section.

§ 34.47 Personnel monitoring.

(a) The licensee may not permit any individual to act as a radiographer or a radiographer's assistant unless, at all times during radiographic operations, each individual wears, on the trunk of the body, a direct reading dosimeter, an operating alarm ratemeter, and a personnel dosimeter that is processed and evaluated by an accredited National Voluntary Laboratory Accreditation Program (NVLAP) processor. At permanent radiography installations where other appropriate alarming or warning devices are in routine use, the wearing of an alarming ratemeter is not required.

(1) Pocket dosimeters must have a range from zero to 2 millisieverts (200 millirems) and must be recharged at the start of each shift. Electronic personal dosimeters may only be used in place of ion-chamber pocket dosimeters.

(2) Each personnel dosimeter must be assigned to and worn only by one individual.

(3) Film badges must be replaced at periods not to exceed one month and other personnel dosimeters processed and evaluated by an accredited NVLAP processor must be replaced at periods not to exceed three months.

(4) After replacement, each personnel dosimeter must be processed as soon as possible.

(b) Direct reading dosimeters such as pocket dosimeters or electronic personal dosimeters, must be read and the exposures recorded at the beginning and end of each shift, and records must be maintained in accordance with § 34.83.

(c) Pocket dosimeters, or electronic personal dosimeters, must be checked at periods not to exceed 12 months for correct response to radiation, and records must be maintained in accordance with § 34.83. Acceptable dosimeters must read within plus or minus 20 percent of the true radiation exposure.